PLEASE PLANT

200-100 Park Royal S, Vancouver, BC
236-323-2179
info@pleaseplant.com
www.pleaseplant.com

THERMAL EXPANSION & CONTRACTION GUIDE

MATERIAL MOVEMENT BEST PRACTICES



Please Plant

Manufacturer: Please Plant
Contact: info@pleaseplant.com | +1 236-323-2179

OVERVIEW

All materials expand and contract with temperature fluctuations, requiring proper installation considerations to maintain performance. Managing material movement effectively prevents warping, cracking, and structural stress over time.

MATERIAL BEHAVIOR

- **Metals** – Aluminum and stainless steel exhibit significant thermal expansion and require movement allowances.
- **Composites & Plastics** – Moderate expansion rates, but prolonged UV exposure can accelerate wear.
- **Concrete & Stone** – Low expansion, yet repeated heating and cooling cycles may cause stress fractures.




INSTALLATION BEST PRACTICES

- **Expansion Joints** – Allow for movement at designated intervals to prevent material distortion.
- **Anchoring & Fasteners** – Use flexible fastening methods that accommodate slight shifts.
- **Spacing & Gaps** – Follow manufacturer recommendations for decking, cladding, and railings to avoid buckling.




ENVIRONMENTAL CONSIDERATIONS

- **High Heat** – Increased expansion requires flexible joints or wider spacing.
- **Cold Climates** – Contraction may cause gaps; select materials suited for extreme temperatures.



EXPANSION JOINTS

Allow for movement at designated intervals to prevent material distortion and stress buildup.



ANCHORING & FASTENERS

Use flexible fastening methods such as slotted holes, oversized holes, or floating clips to accommodate material movement.



MAINTENANCE & COMPLIANCE

Regular inspections ensure structural integrity. Fasteners and joints should be checked periodically, and protective coatings can help mitigate environmental stress.

Please Plant products meet ASTM and ANSI standards for thermal performance, with compliance documentation available upon request.

